


BOSTITCH®

Spring-Powered Stapler LOADING INSTRUCTIONS



1. Flip the stapler upside down and gently push the base (A) up.



2. Gently push the base (A) back to expose the staple channel.



3. With the staple points facing up, drop the staples into the channel (C).



4. Push the base (A) back in place until you hear it click shut.